

Download 9230_UEFI_2.3.0.1067.rar

1. Make a DOS bootable drive on USB disk.
2. Make sure your MB BIOS is the latest version.
3. Unzip attached 9230_UEFI_2.3.0.1067.rar file to bootable USB drive.
4. After boot to DOS, type "go.bat -y" in the command line as below screen shot.

```
C:\9230\UEFI32>go -y

MVF_MAG v1.0.0.2475
**Incoming Image Version**
PACKAGE VERSION: 2.3.0.1067
AUTOLOAD VERSION: 200020
LOADER VERSION: 21001008
UEFI VERSION: 1.1.0.1029
FIRMWARE VERSION: 2.3.0.1078
```

```
----- Adapter 0 Info
DevId:          9230 DevFunc:          00
ClassCode:      0106 RevId:           11
FlashCount      01 SubVer:           00
-----

ImageA1.bin >> /dev_9230/00000000..
Press "Y" to start, other to skip..
Erasing...
Bravo!! Erase Successful!!
Data is flashed perfectly!!

Flashed successful!!!
```

5. Shut down/Reboot the system.