



USB to Serial Adapter

(CB-USB205R)
Quick Installation Guide

w w w . v a n t e c u s a . c o m

Step 1: Driver Installation

The installation steps below apply to Windows 98SE, ME,2000 and XP. Please complete the driver installation first before you connect the adapter.

1. Insert the provided CD into your CD-ROM drive. Run the **Setup** file under **x:\Driver** where x: is your CD-ROM drive letter. When the welcome screen appears, click **Next**.
2. Click **Finish** to complete the installation.

Step 2: Connect the Adapter

Connect the adapter to a free USB port on your computer.

Step 3: Verify the Driver Installation

To verify your adapter installation, select **Control Panel > System > (Hardware) > Device Manager**. Under the **Port (COM & LPT)** group, a string similar to **“USB to Serial Port”** or **“USB-to-Serial CommPort”** should be displayed.

Installation Completed

Now you can connect your RS-232 device to the adapter.

This **Quick Installation Guide** describes only the basic instruction on installation.

For more information, please refer to the **User's Manual** on the provided CD-ROM

USB to Serial Adapter

Model #: CB-USB20SR

www.vantecusa.com

All Registered Trademarks Belong To Their Respective Companies.
Copyright © 2007 Vantec Thermal Technologies. All Rights Reserved.